


POLAR OVER AZIMUTH MOUNT

TR-911



ADJUSTMENTS IN ORDER

1. LATITUDE ANGLE, SET AT SITE LATITUDE ANGLE AND LOCK
2. DECLINATION ANGLE, SET AT AVERAGE SATELLITE DECLINATION ANGLE AND LOCK
3. AZIMUTH ANGLE, LOCK WITH ANTENNA PEAKED ON LOWEST SATELLITE
4. ANTENNA AXIS, THIS IS REPOSITIONABLE FOR DESIRED SATELLITE ACCESS

COMTECH ANTENNA SYSTEMS

FIGURE 1 - 1